

## L480 - 4 STATIONS

- Designed for optimum exercise biomechanics. To guarantee smooth, natural movements for full muscle concentration.
- Calibrated weights. For guaranteed weight person.
- Hard chrome guides and IGUS drylining bushing. Offering a silent, sliding action and minimum maintenance. The bushings are resistant to friction and to high temperatures.
- High resistance 5 mm and 6 mm thick coated Steel cable, for smooth, secure performance.
- 360° free hold, for a more natural exercise, adapted to the anatomical movement of the arms of each particular user, whilst maintaining control. Controlled mobility.
- Magnetic weight plate selectors. The magnets ensure that there is no possibility of the selector coming out during training.
- Stainless steel components. Designed to offer long-lasting durability.
- Use of laser cutting technology, for optimum tube cutting precision.
- Structure of 4 mm thick ST-37/40 steel frame and pulley support plates of 8 mm thick steel frame. Offers guaranteed durability.
- Multiple training positions at the ergoline.
- Weight of exercise adapted to beginners and the most experienced ones.
- Accessories: triceps rope, three short rope grips, two long rope grips and dorsal pull rod.
- Adjustable support in height, in the position of the high pulley with seat.
- Easy access to all elements of control and load selection from the working position of the user.
- Structure raised 50mm above floor level with rubber tipped feet. This provides access for cleaning and vacuuming without scratching the paint.
- Front and rear fairings. Provides greater security to the user during exercise, avoiding accidents while the plates are moving. Easy to clean.
- According to the UNE-EN 957 regulation.
- Legs with rubber protections.

## L480 - 4 STATIONS

- Positions in each tower: high pulley with seat, simple ergoline with adjustable pulley, rowing with short pulley and high pulley without seat.
- Injected core fireproof seat. Unlike the classic foam padded particle boards, the injected core offers the advantage of uniformity, anti-distortion and greater anti-bacterial protection.



### Specifications

**Length:** 335 cm

**Width:** 210 cm

**Height:** 233 cm

Carga en cada polea: 90kg